

Scale: 1" = 20'
Contour Interval = 1'



DITCH SECTION
Scale: 1" = 2'-0"



PIPE JOINTING
Scale: 1" = 1'-0"

DEPARTMENT
CITY OF S
SEWAG
CITY L
TED BY
VED Feb. 26
Ronald E. W
CITY ENGINEER
REGISTERED CIVIL ENGINEER



Scale: 1" = 20'
Contour Interval = 1'



DITCH SECTION
Scale: 1" = 2'-0"



PIPE JOINTING
Scale: 1" = 1'-0"

DEPARTMENT
CITY OF S
SEWAG
CITY L
TED BY
VED Feb. 26
Ronald E. W
CITY ENGINEER
REGISTERED CIVIL ENGINEER



Scale: 1" = 20'
Contour Interval = 1'



DITCH SECTION
Scale: 1" = 2'-0"



PIPE JOINTING
Scale: 1" = 1'-0"

DEPARTMENT
CITY OF S
SEWAG
CITY L
TED BY
VED Feb. 26
Ronald E. W
CITY ENGINEER
REGISTERED CIVIL ENGINEER